



USER INSTRUCTIONS

*Installation
Operation
Maintenance*

Limitorque® MX/QX PROFINET® Field Unit



These instructions must be read prior to installing, operating, and maintaining this equipment.

Contents

1 Introduction 3

1.1 Purpose 3

1.2 How to Use this Manual 3

1.3 User Safety 4

1.4 User Knowledge 4

1.5 Capabilities and Features 4

2 System Components and Installation 5

2.1 Introduction 5

2.2 Hardware 5

2.3 Other Components 6

2.4 Cable Preparation 7

2.5 Installation 8

3 System Configuration and Communication 9

3.1 PROFINET Introduction 9

3.2 Device Configuration 10

3.3 I/O Data Parameters 11

3.4 Alarms 16

3.5 Factory Reset Functions 16

4 Glossary 17

1 Introduction

1.1 Purpose

This manual explains how to install and operate the Flowserve Limitorque MX/QX PROFINET field unit, referred to as the MX (Multi-turn)/QX (Quarter-turn) PN (PROFINET) field unit. Actuators containing the PN field unit may be connected by shielded industrial grade Ethernet cable to form a PROFINET communication system network. The name PROFINET is derived from Ethernet based Process Fieldbus. The PROFINET communication system is a digital, two-way or full-duplex high speed communication bus system that supports communication rate 100 Mbps (100 Base TX).

Information in this User Instruction is believed to be complete and reliable. Despite all Flowserve's efforts to provide comprehensive information and instructions, sound engineering and safety practices should always be used. Please consult with a qualified engineer. Flowserve manufactures products to applicable International Quality Management System Standards as certified and audited by external Quality Assurance organizations. Genuine parts and accessories have been designed, tested, and incorporated into the products to help ensure continued product quality and performance in use. As Flowserve cannot test parts and accessories sourced from other vendors the incorrect incorporation of such parts and accessories may adversely affect the performance and safety features of the product. The failure to properly select, install, or use authorized Flowserve parts and accessories is misuse.

Damage or failure caused by misuse is not covered by Flowserve's warranty. In addition, any modification of Flowserve products or removal of original components may impair the safety of these products in use.

1.2 How to Use this Manual

Each section provides the MX/QX PN user with information on installing and operating the MX/QX PROFINET field unit.

Section 1: Introduction:

The introduction details user safety and knowledge requirements, system capabilities, and features.

Section 2: System Components and Installation:

The system components section focuses on the description of the PROFINET system hardware components and provides details for installing, wiring and configuration of the field unit.

Section 3: System Configuration and Communication:

The system configuration section provides details regarding device and network communication configurations that the MX/QX uses to communicate over the PROFINET.

Section 4: Glossary:

The glossary contains a terminology list of abbreviations, acronyms, and their descriptions.

1.3 User Safety

Safety notices in this manual detail precautions the user must take to reduce the risk of personal injury and damage to the equipment. The user must read and be familiar with these instructions before attempting installation, operation, or maintenance. Work to be performed on the actuator should be carried out by a qualified tradesman familiar with the operation and maintenance of electric actuators. Failure to observe these precautions could result in serious bodily injury or death, damage to the equipment, voiding of the warranty, or operational difficulty.

Safety notices are presented in this manual in three forms:

⚠ WARNING Refers to personal safety. Alerts the user to potential danger. Failure to follow warning notices could result in personal injury or death.

⚠ CAUTION Directs the user's attention to general precautions that, if not followed, could result in personal injury and/or equipment damage.

NOTICE Highlights information critical to the user's understanding of the actuator's installation and operation.

1.4 User Knowledge

It is recommended that the user read this manual in its entirety before the PROFINET option equipped actuator is installed and operated.

The user needs to have fundamental knowledge of electronics and microprocessor concepts. An understanding of valve actuators and digital control systems in the PROFINET context is beneficial to the field unit user.

1.5 Capabilities and Features


- PI certified PROFINET IO device.
- Works with A, B & W Series MX & QX Actuators.
- PROFINET Conformance Class-C according to IEC 61784-2.
- PROFINET Netload Class III.
- 10/100 Mbps Baud with Full-Duplex according to IEEE 802.3x.
- Fast Ethernet 100BASE-TX according to IEEE 802.3u.
- Built-in 2 port Ethernet switch function with auto crossover support.
- Transparent socket interface.
- Support for HTTP forwarding via socket interface.
- Available in dual RJ45 or dual Terminal Block connector options.
- Supports Media Redundancy Protocol (MRP) client functionality.
- Supports S2 System Redundancy.
- Ring/Star/Line topologies supported.
- GSDML file available for download from Flowserve website for network master configuration.

2 System Components and Installation

2.1 Introduction

This section gives an overview of the components used in the PROFINET system. The field unit is installed in each MX/QX actuator. The network cable connects the field unit to the network via the actuator's RJ45 or Terminal Block connectors. The network cable is connected to a host or PROFINET controller.

2.2 Hardware



Figures: PROFINET option board (Field Unit) with dual RJ45 & dual Terminal Block connectors.

Field unit is mounted inside the actuator's terminal compartment and utilizes the auxiliary DC power supply available from the actuator terminals hence no external DC power supply is required for operation of the field unit.

NOTICE The auxiliary DC power supply from the actuator terminals will not be available for customer use for the actuators that are equipped with PROFINET option.

Below table shows the wiring connection details of the PROFINET option board field unit to A/B/W series actuator terminals. Typically, these wiring connections are already done by factory if the actuator is shipped with the PROFINET option board preinstalled.

PN Board J6 Connector Terminal Number	Actuator Terminal Number
1	11
2	10
3*	19*
4	22
5	21

* = Connection between terminal # 3 & 19 is not mandatory for B series actuators.

2.3 Other Components

2.3.1 Jumper Settings

Jumper settings of the field unit are factory preset as shown in the table below, and it is necessary to retain these settings for proper operation of the field unit.

Jumper Between Pins of J7 Connector	Jumper Settings
1 & 2	Ignored.
2 & 3	Jumper MUST NOT be installed.
1 & 3	Ignored.

2.3.2 DIP Switch Settings

DIP switch settings of the field unit are factory preset as shown in the table below, and it is necessary to retain these settings for proper operation of the field unit.

Actuator Type	DIP Switch Settings
A & W Series MX & QX Actuators	Turn ON Switches 1, 3, 4, 5 & 8. Leave 3 remaining switches OFF.
B Series MX & QX Actuators	Turn ON Switches 1, 2 & 6. Leave 5 remaining switches OFF.

2.3.3 LED Indications

NW_L1 (LED1)	Network Status Meaning
Off	No power.
Green	IP address assigned.
Green flashing	IP address not assigned.
Red	IP address conflict error.

MOD_L2 (LED2)	Module Status Meaning
Off	Not in Exception or Wait Process state.
Green	In Wait Process state.
Red	Major fault Exception state. Actuator power cycle required.
Green & Red flashing alternatively	Network module's firmware update in progress.

A_L3 (LED3)	Bottom RJ45 or CH_A or IN Port Status Meaning
Off	No link, no activity.
Green	100 Mbps link established.
Green flashing	100 Mbps link activity on.
Yellow	10 Mbps link established.
Yellow flashing	10 Mbps link activity on.

B_L4 (LED4)	Top RJ45 or CH_B or OUT Port Status Meaning
Off	No link, no activity.
Green	100 Mbps link established.
Green flashing	100 Mbps link activity on.
Yellow	10 Mbps link established.
Yellow flashing	10 Mbps link activity on.

Combinations & Other LEDs	Meaning
LED1 & LED2 both flashing Red	Fatal error occurred. Actuator power cycle may be required.
MB_FLT Red	Mainboard communication fault.
AB_FLT Red	Network module communication fault.
MB_FLT & AB_FLT both flashing Red	PN board configuration invalid. Check jumper & DIP switch settings, Nw module type & board firmware type mismatch.

2.4 Cable Preparation

100 BASE-TX electrical transmission with twisted 2 pairs Cat 5(e) or Cat 6 for transmission over copper can be used. Copper cable can be run in distances of up to 100 meters between field units and switched components. As the field unit supports auto crossover and auto negotiation with a built-in switch, a crossover cable is not required.

Below table describes the field connections of the PROFINET field unit for both types connector options using a 4-Wire PROFINET Type A or Type B cables (these both types of cables carry same wire colors). The wire colors will be different if using other type Ethernet cables and following T568A or T568B termination standards, if so, then make sure to adjust the wire colors as per their standards and only follow any one terminating standard either T568A or T568B and never mix these 2 standards. It is also necessary to make sure these cables are straight-through and not crossover cables.

Signal	PN Cable Wire Color	Both RJ45 Ports Pin Number*	PN Board J2 & J3 Terminal Number*
Transmission Data + TD + or TxD +	Yellow	1	1
Transmission Data – TD – or TxD –	Orange	2	2
Receive Data + RD + or RxD +	White	3	3
Receive Data – RD – or RxD –	Blue	6	4
Shield	Mesh	Shield	5

* = PN board will have either 2 RJ45 ports or 2 five-pin terminal block connectors (as ordered) as described below:

RJ45 Type:

Port-1: Bottom RJ45 connector referenced as Channel A or IN port.

Port-2: Top RJ45 connector referenced as Channel B or OUT port.

NOTICE It is highly recommended to test the correct connection of the RJ45 cables using Cable Tester (Example TRENDnet TC-NT2) before connecting cables to field units.

Terminals Type:

Port-1: J2 five-pin terminal block connector referenced as Channel A or IN port.

Port-2: J3 five-pin terminal block connector referenced as Channel B or OUT port.

2.5 Installation

2.5.1 Electrical Protection

PROFINET cabling should be routed appropriately and laid separately from other plant wiring. Follow NEC rules for Class 2 Circuit installations and IEC 61918 / NEC code. Similar category cables can be bundled in separate channeled cable trays, conduits, etc. Avoid crossing cables of different categories, if they must be crossed then cross them at right angles. PROFINET cables must be laid farther away from the high voltage power supply cables and any interference points and any noise sources like drives, motors, pumps, etc.

Adequate cable separation and grounding the screen at both ends to a low impedance earth “Ze” protects the PROFINET signals against electrostatic and electromagnetic interference. Use meshed equipotential bonding and ground at both ends of a segment, this ensures that the potential is equal in all plant parts, avoids high bonding currents.

Ground cable trays, use bonding bars or clamps for cable entering cabinets, also ground multiple devices along the segment. Recommended use of a Type-MESH-BN (all metallic parts bonded to provide a continuous grounding network).

2.5.2 Mechanical Protection

Use Strain Reliefs:

- Provide strain relief approximately 30cm away from the connecting terminals for all cables that are subjected to tensile strain.

Prevent Wire Break & Short Circuits:

- Use cable trays or protection tubes.
- Avoid heavy mechanical stress using metal conduits.
- Avoid medium mechanical stress using plastic conduits.
- Use metal conduits or covered cable trays if cable crosses the walkway or driveway.
- Avoid sharp edges. Use edge protection measures. Deburr sharp edges.

Tensile Strength & Force:

- If pulling the cable past the tensile strength (> 150 N) can damage the cable.
- Pull by hand if possible.
- Use strain relief if necessary.
- Do not use too much force for pulling the cables.

Bending Radius:

- Sharp bends can break the cable over time and cause reflections (typically from 20 to 65mm for cable type B & C, and 50 to 100mm for cable type A).
- Make sure all bends are within the allowed radii.
- If necessary, use guided pulleys or cable channels to prevent loops & kinks.
- Do not twist the cable(s).
- Rotate the cable from a cable drum rather than doing this by hand.

Temperature Limits:

- Note cable temperature limits provided by manufacturers.

3 System Configuration and Communication

3.1 PROFINET Introduction

PROFINET (Process Field Network) is an open industrial Ethernet protocol used for real-time data communication in industrial automation and control systems. Managed and supported by PROFIBUS & PROFINET International (PI), it is a powerful communication standard that connects programmable logic controllers (PLCs) with field devices such as sensors, actuators, drives, etc.

PROFINET is based on standard Ethernet, which allows it to coexist with other Ethernet protocols like TCP/IP on the same network infrastructure. However, to meet the strict timing demands of industrial automation, PROFINET bypasses the TCP/IP layers for time-critical data, using specialized communication channels.

Scalability and Flexibility: PROFINET supports various network topologies, including line, star, and ring, and can use copper media for communication with redundancy capabilities.

Advanced Diagnostics: Provides detailed, vendor-independent network and device diagnostics that allow for remote monitoring, fast fault location, and reduced downtime.

Simple Device Replacement: Allows a failed device to be swapped with a new one without requiring manual configuration. The controller automatically reassigns the necessary parameters.

Support for Digitalization: As an Ethernet-based protocol, PROFINET easily integrates with higher-level IT systems and is equipped for Industry 4.0 applications, such as the Industrial Internet of Things (IIoT).

Fieldbus Integration: Protects legacy investments by allowing older fieldbus systems, like PROFIBUS, to be easily integrated into a PROFINET network using gateways or proxies.

3.2 Device Configuration

3.2.1 Mandatory Actuator Configurations

Users must download the latest version of relevant Actuator's (MX/QX) Instruction and Operation Manual (IOM) from the Flowserve website and follow the basic installation and commissioning procedure including limit and torque settings before proceeding for the PROFINET specific configurations explained in the next steps.

NOTICE No PROFINET specific user accessible configurations are available via local interface of the actuator. Refer following instructions for PROFINET specific configurations.

3.2.2 Mandatory PROFINET Configurations

Field unit's PI certified PROFINET GSDML file can be downloaded from the Flowserve website and must be used with the users' host system to configure the field unit into the user's PROFINET controllers.

For remote access and control of the field unit users must also set all the network communication parameters of the field unit like PROFINET device name, IP address, Subnet mask, etc. The PROFINET device name and IP address must be unique value within a subnet. This can be done using any network configuration tool that supports Discovery and Configuration Protocol (DCP) like PRONETA®, SIMATIC®, STEP7®, TIA Portal®, PROFINET Commander, HMS PROFINET Master Simulator, etc.

3.2.3 Optional Configurations

Optionally users can utilize the field unit's I&M records for identification and maintenance purpose of the associated actuator and valve. This step is not mandatory for field unit's remote access and operation.

3.3 I/O Data Parameters

Following input/output data parameters are accessible via both cyclically and acyclically.

Parameter	I/O (Access)	Data Type	Description (Refer below for more details)
01_Argument	Output (RW)	UINT16	Argument for Actuator Command.
02_Command	Output (RW)	UINT16	Actuator Command.
03_Position	Input (RO)	UINT16	Actuator current position value in % open.
04_DO1	Input (RO)	UINT16	Digital output 1.
05_DO2	Input (RO)	UINT16	Digital output 2.
06_DO3	Input (RO)	UINT16	Digital output 3.
07_PercentTorque	Input (RO)	UINT16	Actuator current torque in % unit rating.
08_InternalTemp	Input (RO)	UINT16	Actuator internal temperature.
09_MainsVoltage	Input (RO)	UINT16	Actuator mains voltage.
10_DI1	Input (RO)	UINT16	Digital input 1.
11_DI2	Input (RO)	UINT16	Digital input 2.
12_AO1	Input (RO)	UINT16	Analog output 1 value.
13_AI1	Input (RO)	UINT16	Analog input 1 value.
14_AO2	Input (RO)	UINT16	Analog output 2 value.
15_AI2	Input (RO)	UINT16	Analog input 2 value.
16_Future3	Input (RO)	UINT16	Future use 3.
17_Future2	Input (RO)	UINT16	Future use 2.
18_Future1	Input (RO)	UINT16	Future use 1.

3.3.1 01_Argument and 02_Command

Following Command and Argument values are supported.

3.3.1.1 Move Commands

Function	02_Command Hexadecimal (Decimal) Value	01_Argument Hex (Decimal)	Description
No Command	0x0000 (0)	Ignored	Clear Command parameter.
Run Open	0x0100 (256)	Ignored	Full open command.
Stop Running	0x0200 (512)	Ignored	Stop command.
Run Close	0x0300 (768)	Ignored	Full close command.
1 Register Move-To Command	0xXX4B (0xXX00 + 75) Example values: 0% Move-To = 0x004B (75). 50% Move-To = 0x324B (12,875). 100% Move-To = 0x644B (25,675).	Ignored	Single register Move-To command. Most significant byte value (XX) is the desired actuator position value in hexadecimal; valid range from 0% to 100%.
2 Registers Move-To Command	0x1A00 (6,656)	Desired actuator position value; valid range from 0x0000 (0) to 0x0064 (100).	Dual registers Move-To command. Move to desired position value mentioned in Argument parameter. NOTICE Always write Argument value first and then write value 0x1A00 (6,656) to Command parameter.

3.3.1.2 Multiport Move Commands

NOTICE Applicable only for actuators equipped with Multiport option.

Function	02_Command Hex (Decimal) Value	Description
No Command	0x0000 (0)	Clear Command parameter.
Move-To Home	0x2000 (8,192)	Move to Home position.
Move-To Port-1	0x2100 (8,448)	Move to Port-1 position.
Move-To Port-2	0x2200 (8,704)	Move to Port-2 position.
Move-To Port-3	0x2300 (8,960)	Move to Port-3 position.
Move-To Port-4	0x2400 (9,216)	Move to Port-4 position.
Move-To Port-5	0x2500 (9,472)	Move to Port-5 position.
Move-To Port-6	0x2600 (9,728)	Move to Port-6 position.
Move-To Port-7	0x2700 (9,984)	Move to Port-7 position.

3.3.1.3 Relay Commands

NOTICE Works only if respective relay's function is set to Network Controlled.

Function	02_Command Hex (Decimal) Value	Description
No Command	0x0000 (0)	Clear Command parameter.
Set S1 Relay	0x0900 (2,304)	Energize S1 relay.
Clear S1 Relay	0x1100 (4,352)	Deenergize S1 relay.
Set S2 Relay	0x0A00 (2,560)	Energize S2 relay.
Clear S2 Relay	0x1200 (4,608)	Deenergize S2 relay.
Set S3 Relay	0x0B00 (2,816)	Energize S3 relay. NOTICE Not for series A, W units without Relay Board-1 option.
Clear S3 Relay	0x1300 (4,864)	Deenergize S3 relay. NOTICE Not for series A, W units without Relay Board-1 option.
Set S4 Relay	0x0C00 (3,072)	Energize S4 relay. NOTICE Not for series A, W units without Relay Board-1 option.
Clear S4 Relay	0x1400 (5,120)	Deenergize S4 relay. NOTICE Not for series A, W units without Relay Board-1 option.
Set R1 Relay	0x0D00 (3,328)	Energize R1 relay. NOTICE For units with Relay Board-2 option.
Clear R1 Relay	0x1500 (5,376)	Deenergize R1 relay. NOTICE For units with Relay Board-2 option.
Set R2 Relay	0x0E00 (3,584)	Energize R2 relay. NOTICE For units with Relay Board-2 option.
Clear R2 Relay	0x1600 (5,632)	Deenergize R2 relay. NOTICE For units with Relay Board-2 option.
Set R3 Relay	0x0F00 (3,840)	Energize R3 relay. NOTICE For units with Relay Board-2 option.
Clear R3 Relay	0x1700 (5,888)	Deenergize R3 relay. NOTICE For units with Relay Board-2 option.
Set R4 Relay	0x1B00 (6,912)	Energize R4 relay. NOTICE For units with Relay Board-2 option.
Clear R4 Relay	0x1C00 (7,168)	Deenergize R4 relay. NOTICE For units with Relay Board-2 option.

3.3.2 04_DO1

Bit descriptions of Digital Output 1 parameter.

Bit #	Bit Mask Value Hex (Decimal)	Description
0	0x0001 (1)	Fully opened.
1	0x0002 (2)	Fully closed.
2	0x0004 (4)	Stopped in mid-travel or mid-position.
3	0x0008 (8)	Opening.
4	0x0010 (16)	Closing.
5	0x0020 (32)	Valve jammed.
6	0x0040 (64)	Not in remote.
7	0x0080 (128)	Combined fault.
8	0x0100 (256)	Motor overtemperature or Thermistor fault.
9	0x0200 (512)	Knob in Stop.
10	0x0400 (1,024)	Reserved.
11	0x0800 (2,048)	Reserved.
12	0x1000 (4,096)	Open torque fault (not torque limit).
13	0x2000 (8,192)	Close torque fault (not torque limit).
14	0x4000 (16,384)	Moved manually.
15	0x8000 (32,768)	Lost phase or reverse phase sequence.

3.3.3 05_DO2

Bit descriptions of Digital Output 2 parameter.

Bit #	Bit Mask Value Hex (Decimal)	Description
0	0x0001 (1)	Open inhibit active.
1	0x0002 (2)	Close inhibit active.
2	0x0004 (4)	Reserved.
3	0x0008 (8)	Reserved.
4	0x0010 (16)	Lost phase.
5	0x0020 (32)	Reverse phase sequence.
6	0x0040 (64)	ESD conflict.
7	0x0080 (128)	Inhibit conflict.
8	0x0100 (256)	CSE in Local or Stop and has control.
9	0x0200 (512)	Input Data Too Old.
10	0x0400 (1,024)	Network ESD active.
11	0x0800 (2,048)	Local ESD active.
12	0x1000 (4,096)	Main board CPU reset.
13	0x2000 (8,192)	Knob in Stop.
14	0x4000 (16,384)	Opening in Local.
15	0x8000 (32,768)	Closing in Local.

CAUTION If Bit # 9 “Input Data Too Old” is set then the field unit will also send out an alarm channel # 1289 to the PROFINET Controller. Users must discard all input data (including remaining bits in this parameter except for this bit # 9) read from the field unit while this bit is set; this indicates the field unit's communication link with the internal CPU is either busy or interrupted, hence the input data read is not updated and may be same as previously read values. Users can use this bit as a data quality bit (0=Good, 1=Bad) for all input data read by the PROFINET Controller. This bit will be cleared or reset automatically by the field unit in the subsequent reads. If this bit is not cleared by itself then check the wiring between the PROFINET option board (field unit) and the actuator terminals in the actuator terminal compartment. If you need further assistance, please contact Limatorque service personnel.

3.3.4 06_DO3

Bit descriptions of Digital Output 3 parameter.

Bit #	Bit Mask Value Hex (Decimal)	Description
0	0x0001 (1)	Closing.
1	0x0002 (2)	Opening.
2	0x0004 (4)	S1 relay energized.
3	0x0008 (8)	S2 relay energized.
4	0x0010 (16)	S3 relay energized.
5	0x0020 (32)	S4 relay energized.
6	0x0040 (64)	R1 relay energized.
7	0x0080 (128)	R2 relay energized.
8	0x0100 (256)	R3 relay energized.
9	0x0200 (512)	Network bypass relay energized.
10	0x0400 (1,024)	R4 relay energized.
11	0x0800 (2,048)	Not used.
12	0x1000 (4,096)	Reserved.
13	0x2000 (8,192)	Reserved.
14	0x4000 (16,384)	Reserved.
15	0x8000 (32,768)	Reserved.

3.3.5 10_DI1

Bit descriptions of Digital Input 1 parameter.

Bit #	Bit Mask Value Hex (Decimal)	Description
0	0x0001 (1)	Knob in Remote.
1	0x0002 (2)	Motor overtemperature or Thermistor fault.
2	0x0004 (4)	Open torque limit.
3	0x0008 (8)	Open position limit.
4	0x0010 (16)	Close torque limit.
5	0x0020 (32)	Close position limit.
6	0x0040 (64)	Analog board-2 AI lost.
7	0x0080 (128)	Quick power board present.
8	0x0100 (256)	User Input 0.
9	0x0200 (512)	User Input 1.
10	0x0400 (1,024)	User Input 2.
11	0x0800 (2,048)	User Input 3.
12	0x1000 (4,096)	User Input 4.
13	0x2000 (8,192)	User Input 5.
14	0x4000 (16,384)	User Input 6.
15	0x8000 (32,768)	User Input 7.

3.3.6 11_DI2

Bit descriptions of Digital Input 2 parameter.

Bit #	Bit Mask Value Hex (Decimal)	Description
0	0x0001 (1)	Analog board-1 present.
1	0x0002 (2)	Analog board-2 present.
2	0x0004 (4)	Mainboard AI lost.
3	0x0008 (8)	Analog board-1 AI lost.
4	0x0010 (16)	Reserved.
5	0x0020 (32)	Relay board-2 present.
6	0x0040 (64)	Modbus board present.
7	0x0080 (128)	Relay board-1 present.
8	0x0100 (256)	FOUNDATION Fieldbus board present.
9	0x0200 (512)	PROFIBUS PA board present.
10	0x0400 (1,024)	CSE selected for User Input 2.
11	0x0800 (2,048)	DeviceNet board present.
12	0x1000 (4,096)	Lost phase.
13	0x2000 (8,192)	Reverse phase sequence.
14	0x4000 (16,384)	User Input 8.
15	0x8000 (32,768)	PROFIBUS DP board present.

3.4 Alarms

Following Extended Channel Diagnosis Alarms are supported.

Channel Number Decimal Value	Channel Number Hexadecimal Value	Alarm Description
1029	0x0405	Valve Jammed.
1030	0x0406	Not in Remote.
1031	0x0407	Combined Fault.
1032	0x0408	Motor Overtemperature.
1033	0x0409	Knob in Stop.
1036	0x040C	Open Torque Fault.
1037	0x040D	Close Torque Fault.
1038	0x040E	Moved Manually.
1039	0x040F	Lost Phase or Reverse Phase.
1280	0x0500	Open Inhibit Active.
1281	0x0501	Close Inhibit Active.
1286	0x0506	ESD Conflict.
1287	0x0507	Inhibit Conflict.
1288	0x0508	CSE in Local or Stop.
1289	0x0509	Input Data Too Old.
1290	0x050A	Network ESD Active.
1291	0x050B	Local ESD Active.
1545	0x0609	Network Bypass Relay.
2562	0x0A02	Open Torque Limit.
2564	0x0A04	Close Torque Limit.
2566	0x0A06	Analog Board-2 AI Lost.
2818	0x0B02	Mainboard AI Lost.
2819	0x0B03	Analog Board-1 AI Lost.

3.5 Factory Reset Functions

Following PROFINET factory reset functions are supported.

NOTICE All these commands will cause the field unit to drop offline. User must reassign PROFINET Device Name, IP address, Subnet mask & Gateway address to reestablish the communication with the field unit.

3.5.1 Mode 0

Reset Device, Optional Function.

3.5.2 Mode 2

Reset Communication Parameters, Mandatory & Default Function.

3.5.3 Mode 8

Reset Device, Optional Function.

4 Glossary

= Number.

AI = Analog Input.

AO = Analog Output.

CPU = Central Processing Unit.

DCS = Distributed Control System.

DegC = Degrees Celsius.

DegF = Degrees Fahrenheit.

DI = Digital Input.

DIP = Dual In-Line Package.

DO = Digital Output.

ESD = Emergency Shutdown.

GSDML = Generic Station Description Markup Language.

Hex = Hexadecimal.

IEC = International Electromechanical Commission.

IEEE = Institute of Electrical & Electronics Engineers.

I/O or IO = Input Output.

IP = Internet Protocol.

LED = Light Emitting Diode.

Mbps = Mega bits per second.

N = Newton.

Nw = Network.

PLC = Programmable Logic Controller.

PI = PROFIBUS & PROFINET International.

PN = PROFINET.

TCP = Transmission Control Protocol.

UDP = User Datagram Protocol.

UINT16 = Unsigned Integer with 16 Bits or 2 Bytes.

V or v = Version.

XML = Extensible Markup Language.



United States

Flowserve Limatorque
5114 Woodall Road,
P.O. Box 11318
Lynchburg, VA 24506-1318
Phone: +1 (434) 528-4400
Fax: +1 (434) 845-9736

Local Flowserve representative:

To find your local Flowserve representative use the Sales Support Locator System found at www.flowserve.com or email
LimatorqueService@Flowserve.com

Headquarters

Flowserve Corporation
5215 North O'Connor Blvd.
Suite 700
Irving, Texas 75039-5421 USA

Flowserve Corporation has established industry leadership in the design and manufacture of its products. When properly selected, this Flowserve product is designed to perform its intended function safely during its useful life. However, the purchaser or user of Flowserve products should be aware that Flowserve products might be used in numerous applications under a wide variety of industrial service conditions. Although Flowserve can provide general guidelines, it cannot provide specific data and warnings for all possible applications. The purchaser/user must therefore assume the ultimate responsibility for the proper sizing and selection, installation, operation, and maintenance of Flowserve products. The purchaser/user should read and understand the Installation Instructions included with the product, and train its employees and contractors in the safe use of Flowserve products in connection with the specific application.

While the information and specifications contained in this literature are believed to be accurate, they are supplied for informative purposes only and should not be considered certified or as a guarantee of satisfactory results by reliance thereon. Nothing contained herein is to be construed as a warranty or guarantee, express or implied, regarding any matter with respect to this product. Because Flowserve is continually improving and upgrading its product design, the specifications, dimensions and information contained herein are subject to change without notice. Should any question arise concerning these provisions, the purchaser/user should contact Flowserve Corporation at any one of its worldwide operations or offices.

©2026 Flowserve Corporation. All rights reserved. This document contains registered and unregistered trademarks of Flowserve Corporation. Other company, product, or service names may be trademarks or service marks of their respective companies.

AI10M003262-00 (EN/LTR) August 2026